

"World Famous Reliable Motor Scooters, Parts & Maintenance"



Roberta, GA 31078-0397
(478) 238-9777
www.ecobikeusa.com

QT-2 RACK INSTALLATION



Notes:

- 1. You may have to spread (bend) support arms apart some so the rack connect points will line up with screw holes on scooter. Make trial fits. Avoid support arms scratching scooter finish.**
- 2. If your scooter does not already contain 6mm bolts on the seat back rest underside to remove and re-use to mount the top rack support arms, buy locally from a hardware or autoparts store. About .45 cents each.**
- 3. Lubricate any bolts you remove from scooter to install rack before you put them back in to mount the rack. Use any light oil and start back in by hand.**